

COVE

PERFORMANCE EXHAUST

2018+ HD SOFTAIL SYSTEMS

PN's Starting with:CP-559, CP-561 , CP-562 w/ or w/out Luggage



BILL OF MATERIALS

1	Muffler	VARIES
1	Front Header	CP-55901HF
1	Rear Header	CP-55901HR
2	O2 Sensor Plug Kit	CP-92-22KIT
2	45mm Swivel Hook Spring	CP-S45
1	Spring Puller	CP-SP
2	Harley 5/16 Clip Nut	CP-516CN
3	5/16" x 3/4" Flange Bolt	CP-FB51634
2	5/16" x 1 1/2" Flange Bolt	CP-FB516112
1	Mounting Bracket	CP-559-B
1	5/16"-24 x 1 1/4" Socket Head Cap Screw	CP-516114-24
1	Luggage Bracket	CP-559-SGB

INSTALLATION INSTRUCTIONS

1. Make sure the motorcycle is completely cool before installation. Make sure the motorcycle is secure on a stand or service lift.
2. Remove both the OEM heat shields, muffler and muffler bracket. (Reference images 1 & 2)



3. Remove the OEM front and rear O2 sensors from the header pipes
4. Remove OEM foot controls
5. Loosen and remove the oem header flange bolts and remove headers



6. Install Oem flanges, c clips, and o2 sensors onto the CP headers using the o2 sensor reducers (ref. 3 and 4)
7. Now loosely install the front and rear CP headers. (Reference image 5)
8. Install the CP trans bracket using the included 5/16" x 1 1/2" bolts. Hold the bracket up while tightening (Reference image 6)



9. Install the muffler onto the bike and use the included springs and 5/16"x3/4" Bolts. dont tighten (Reference images 7 & 8)



10. If you have a wide tire and have the passenger peg ref image 9, if you have luggage ref 10 (18-24 use top hole 25+ use bottom hole)
11. now you can tighten the headers and muffler bolts, hold the muffler up while you snug everything up
12. (Bikes with luggage brackets) Remove right hand passenger peg for 18-24 models using the top hole in frame
13. Install supplied bracket to OEM luggage mount and passenger peg mounting location using 5/16 x 3/4 flange bolt and reinstall passenger peg in standard location. (Reference Image 10) . only PN's for luggage include these parts
14. Double check your work to make sure everything is secure
15. Wipe down all the headers and muffler with a cleaner that wont leave any residue. if you dont you will burn all the finger prints and oils into the metal.



Image 9



Image 10

