

**Part Number:** HDFLH-F4-CVO  
 HDFLH-H4-CVO  
 HDFLH-GAM4-CVO  
 HDFLH-STNG4-CVO  
 HD-RKF-4-CUS  
 HD-RKH-4-CUS

HD-FLH-97-STNG  
 HD-FLH-97-GAM  
 HD-FLH-97-YG  
 HD-FLHX-6-YG  
 HD-RK-6-YG



**Description:** #A00525 Seat-Mounting Pin Bracket

**Fitment:** 2004+ Harley-Davidson FLH, FLHX & Road King

**Revision:** 4

Tools Required	Parts List
7/16 Allen wrench	#A00525 Seat Mounting Pin Bracket 2 1/4 x 20 Nylock Nuts 2 1/4" x 1" Flat Washers

**NOTE:** Seats do **NOT** fit with Rear Crash Guards installed on FLHX Street Glide models.

1. Start by removing the stock seat from your motorcycle providing access to the mounting area for your new saddle. Refer to your owner's manual if necessary.

**NOTE:** We highly recommend using a removable strength thread lock product such as Loc-tite® on the bolts when installing your mounting bracket.

2. Remove the existing nuts from the OEM solo seat mounting points on the front of the rear fender, if present.

3. Position the bracket with the mounting pin oriented towards the front of the bike. Secure with the flat washer and nylock nut provided.

(Figure 1 & 2)

4. Your new Corbin saddle is now ready to install by slipping the front tab into the slot by the rear of the gas tank, centering the seat over the mounting pin and with a gentle push downward, your saddle will lock into place.

**NOTE:** If your saddle does not latch, it's due to the rubber grommets needing time to break in. To latch your saddle, adjust the latch pin upwards with one or two washers.



**FIG 1**



**FIG 2**

**Questions? Give us a holler...**  
**800-223-4332**  
**tech@corbin.com**