

Part Number: HD-ST-ROD-G & HD-ST-ROD-GL

Description: Gunfighter and Gunfighter & Lady Saddle

Fitment: 2017-2018 Harley-Davidson Street Rod

Revision: 2



Tools Required	Parts List
7/16" socket or combination wrench 7/16 open wrench 6mm open wrench 10mm socket and open wrench	1 #P01606 Latch Pin 2 #SP01080 Washers 1 #SP00123 Nylock Nut

NOTE: We recommend the use of Loctite® or similar thread lock compound when assembling parts on your motorcycle.

1. Your new Corbin solo saddle installs a bit different than your stock seat in order to use a new key-lock system. Latch Pin installation is a one-time deal, then your new saddle will go on and off with the included keys.



FIG 1

2. Start by removing your stock seat and belt strap. Remove the stock pin, using a 6mm open wrench (*Figure 1*).



FIG 2

3. Next remove the four bolts and washers on the tail section, using a 10mm socket wrench (*Figure 2*).

NOTE: The belt strap isn't shown in *Figure 2*, but it's held in place with the two front bolts and flat washers. You will not be reusing the belt strap.

4. Remove tail section (*Figure 3*).



FIG 3

5. Install the latch pin and flat washer on the tail section (*Figure 4*) and secure with the provided flat washer and nylock nut (*Figure 5*), using a 7/16" open wrench.

6. Reinstall the tail section onto the bike, using the stock bolts and washers (*Figure 6*).

5. To install your saddle, slide the front tab on the saddle under the tab at the rear of the gas tank, then align the rear of the saddle with the latch pin you just installed. Push down until you hear it click (*Figures 7*).



Questions? Give us a holler...
800-223-4332
tech@corbin.com