

Part Number: HD-XL-ST-7-G & HD-XL-ST-7-CG
HD-XL-CU-7-G & HD-XL-CU-7-CG



Description: Gunfighter Saddle

Fitment: Harley-Davidson Sportster

Revision: 1

Tools Required	Parts List
7/16 Open Wrench 12" Zip Tie	#P00537 Mounting Pin #P00545 Plastic Cup #DS-490045 Harley-Davidson Fender Nut

NOTE: We recommend the use of Loctite® or similar thread lock compound when assembling parts on your motorcycle.

1. Thread the Harley-Davidson fender nut onto a 12" zip tie or a piece of wire. Zip ties work great because they already have an end on them that stops the nutsert from sliding off. If you use wire, just put a couple of bends in the bottom end.

2. Now thread the zip tie or wire up through the first fender hole (Figure 2). You can do this from either side.

3. Pull the zip tie up and rotate as necessary to align the nutsert properly in the fender hole. Hold it in place with the zip tie and install the plastic C-clip.

4. Now install our mounting pin and plastic cup onto the fender nut you just installed (Figure 3). Use a 7/16" open wrench to secure it in place. Slip the tongue of the saddle into the slot by the gas tank, making sure it is snug to the tank. Center the rear of the seat over the pin and firmly push down to latch. Use the Corbin seat key to unlock the latch and remove the saddle.



Questions? Give us a holler...
800-223-4332
tech@corbin.com