



PASSENGER ARMRESTS

WARNING This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

CAUTION This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.

ATTENTION This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation. Read completely and understand the instructions prior to starting installation.

NOTE: Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a limited lifetime warranty against LED failure. Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed, unmodified and maintained. Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products. Please visit Ciro3d.com for our complete warranty policy.

Included Items:



Installation Instructions:

1. Park on a level surface and shut off motorcycle. Ensure the engine has time to cool before installation. Protect the areas of the motorcycle where you will be working.
2. You will need to remove the existing backrest cover. Open the trunk and remove the screw shown in Fig. 1 and set aside. There is another screw at the bottom of the backrest shown in Fig. 2. To access, remove the three screws shown in Fig. 2 and the backrest will flex out from the trunk. Remove the small screw indicated in Fig. 2 and remove the faceplate cover and set aside. Replace the three screws removed holding the backrest. Be careful not to overtighten.
3. Insert the armrest attachment link through the backside of the hinge mechanism. Fig. 3
4. Slide the armrest into the hole exposed by the plastic cover and align its mounting holes with the armrest attachment link. Note: The accessory mounting hole in the arm faces out. Fig. 4
5. Install the provided screws with washers through the armrest attachment link. Fig. 5
6. Repeat steps 2-5 on the other side of the motorcycle.

NOTE: If installing an accessory mount remove the arm plug and refer to the directions included with the mount. Fig. 6



