



CONSTRICTOR™ PHONE HOLDER

WARNING This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

CAUTION This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.

ATTENTION This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation. Read completely and understand the instructions prior to starting installation.

NOTE: Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a limited lifetime warranty against LED failure. Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed, unmodified and maintained. Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products. Please visit Ciro3d.com for our complete warranty policy.

Included Items:



Fig.1



Installation Instructions:

1. Park motorcycle on level surface and allow sufficient time for engine to cool.
2. Determine where you want to mount the Constrictor™ and install the appropriate mount. Follow the instructions provided with the mounting kit (sold separately).
3. Place collet nut over ball mount with threads out. Push phone holder over ball and place collet nut onto threads and tighten until snug. **Whenever you reposition the phone holder always loosen the collet nut first, then reposition and retighten.**

Fig.1

4. If desired, cam lever can be positioned on the other side by loosening cam screw all the way reversing to other side and retighten.
5. Place phone in holder and adjust cam lever to just be able to place and remove phone with slight pressure. Close cam lever to lock phone in position.
6. For a larger phone, the leg can be lowered by loosening the three screws on the back, adjust, and retighten. Fig. 2

Fig.2

