



Installation instructions for Mustang Solo seat for 1983-2013 Police Air-Ride models

Stock seat removal

1. Pivot stock seat up to reveal mounting bolts.
2. Unscrew three bolts from bottom of stock seat. These bolts will not be used with the Mustang solo seat.
3. Remove stock seat from the pivoting bracket.



Mustang seat installation

1. Remove hex nuts from studs on bottom of Mustang solo seat.
2. Position Mustang solo seat onto pivoting bracket, aligning the three threaded studs with the holes in the bracket.
3. Install the three supplied hex nuts and tighten.
4. Pivot seat into riding position.



Note: Between 1983 and 2011, the stock pivoting brackets have gone through some changes, but the mounting hole pattern has remained constant, and this enables the Mustang police solo to be used on any year within this range without the need for any alteration or extra hardware.

Mustang Seat
#79549
shown



These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".
Ref: part #'s 76455, 76456, 79548, 79549