



MOTORCYCLE SEATS

Mounting Suggestions Harley-Davidson® Sportster 2004 - 2013 Passenger Seat

Tools Required:

- Phillips Screwdriver
- Allen Wrench Set

Hardware:

- 1/4-20 x 1" Allen Bolt (Included)
- Spool Washer (Included)



Baseplate Features:

The baseplate is made of marine-grade fiberglass, 3/16" thick, finished in high gloss gel coat. Polyurethane rubber bumpers prevent it from touching the frame and fender and minimize vibration.

Mounting of Mustang Seat

1. Remove stock fender screw from rear tab of Mustang solo seat.
2. Install supplied 1/4-20x1" Allen bolt and spool washer in its place.
3. Slide slotted rear seat onto spool washer. (Fig. I)
4. Secure passenger seat to the fender with stock fender screw to complete the installation process.

Fig. I



Enjoy the Comfort of your new Mustang Seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 75542, 76501, 76503, 76507, 76505, 79379, 79377, 76725, 76727, 76729, 76731