

Mounting Suggestions 2009 – 2013 Triumph Thunderbird Two-Piece Seat

Hardware Included: (2) 6mm x 25mm hex bolt (2) Chrome spool washer

Removal of Stock Seat (seats are 2-piece and are the same on the 2009-13 1600cc Thunderbird and the 2011-13 1700cc Storm)

- 1. Using a 5mm Allen wrench, remove the 6mm rear seat mounting screw from the fender.
- 2. Slide the rear seat back out of the front fender bracket, up and off of the fender.
- 3. With the rear seat removed, remove the solo seat side mounting bolts located ahead of the shocks using a 5mm Allen wrench.
- 4. Lift the rear of the solo up and off the frame and then towards the rear to disengage the nose bracket that is under the gas tank.







Installation of Mustang Solo Seat

Note: Stock Passenger Seat WILL NOT FIT with Mustang Solo Seat.

- 1. Before installing Mustang seat, remove seat bracket from fender and install supplied chrome spool washers onto Mustang 6mm bolts and thread into fender. Tighten with a 10mm wrench.
- 2. Place the solo seat onto the frame, sliding it forward to engage the nose bracket under the gas tank. Do not install side bolts yet.
- 3. Align the rear seat fork brackets with the spool washers on the fender. Slide the rear seat forward, engaging the brackets into the spool washers.
- 4. Install the stock 6mm screw through the rear seat bracket and into fender. Tighten with a 5mm Allen wrench.
- 5. Align solo brackets with the mounts on each side of the frame and then install stock 6mm bolts. Tighten with a 5mm Allen wrench.

These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to <u>questions@mustangseats.com</u> or visit our website at <u>www.mustangseats.com</u>.

For care and maintenance of our seats, please go to our website under <u>"Support"</u>.

Ref: part #s 76830, 76831, 79816, 79824, 76832, 76833, 76834, 76835, 79817, 79818, 79825, 79826

Install supplied chrome spool washers onto 6mm bolts



Remove bracket









