

MOUNTING SUGGESTIONS:

Suzuki 700/750/800 Intruder '85-04 & S50 '05-09

One-piece Seat

Hardware: Stock 5mm front bolts

Tools needed: Metric Allen wrenches

Removal of stock seat:

1. Remove both side covers and locate and remove the two 5mm Allen bolts at the front of the solo. These will be used to mount your new Mustang seat.



- 2. Lift the solo up and forward to remove.
- 3. Note that the ECM is attached to the baseplate of the passenger seat. Remove the 10mm bolts from the fender bracket and *carefully* slide the passenger seat forward and up off the motorcycle.
- 4. Before fully removing the passenger seat, carefully remove the ECM from the passenger seat.
- 5. Re-install the 10mm bolts into the fender. Route the wires to the outside of the bolts.

Installation of Mustang seat:

- 1. Clip the ECM to the baseplate of the seat.
- 2. Engage the seat's rear bracket into the rear fender receiver.
- 3. Install the two 5mm Allen bolts through the front seat bracket and into the frame. Tighten securely, and re-install the side covers.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part number: 75284, 75285

You are cordially invited to Tour the Mustang Factory-

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.