



INSTALLATION

NECK COVERS/07-UP FLST MODELS (EXCEPT FLSTS MODELS)

7833

PARTS INCLUDED

- 1 Right Side Neck Cover
- 1 Left Side Neck Cover
- 1 Hardware Kit including:
 - 1 8-32 x 1.86" Hex Coupler Nut
 - 1 3/8"-16 x 4 3/8" Double Threaded Tank Bolt
 - 2 3/8" x 0.812" x 0.120" Spacers (**not used**)
 - 2 #8-32 x 7/16" Socket Head Cap Screws (SHCS)
 - 2 #8 Split Lock Washers
 - 2 3/8" Flat Washer
 - 2 3/8"-16 High Crown Acorn Nut
- 1 Hardware Kit including:
 - 1 4" Corrugated Wire Cover
 - 4 Nylon Cable Ties
 - 1 Cord Keeper
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

CAUTION! This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

TOOLS SUGGESTED

Set of Hex Wrenches, Combination Wrenches or Socket Set and Ratchet.

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

CAUTION! Avoid damage to the motorcycle. Protect painted surfaces with a soft cloth or blanket.

STEP 2 Remove the front gas tank mounting nut and bolt as shown in PIC.1.

STEP 3 Install the hex coupler nut to the right side neck cover using a #8-32 x 7/16" SHCS screw and #8 split lock washer as shown in PIC.2; do not tighten the screw yet.

7833-22HD-0311

-cont.-



CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
 - The product must be properly installed, maintained and operated under normal conditions.
 - Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
 - Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.

• Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.

• Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Kuryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year. This includes, but is not limited to; control modules, wiring, chrome & other components.

• Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

For purchasing Kuryakyn® products, you can receive a complete catalog free of charge.

Send the Proof-of-Purchase below with your address to: Kuryakyn, P.O. Box 339, Somerset, WI 54025.

Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Kuryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA® All Rights reserved.

kuryakyn.com



STEP 4 Insert the 3/8"-16 x 4 3/8" Double Threaded Tank Bolt through the gas tank mounting holes.

STEP 5 Place the right side cover in place, over the tank-mounting bolt. Make sure that the wires are behind the cover and not being pinched. The throttle cables remain outside of the cover and lie in the notch at the back of the neck cover as shown in PIC.3.

ATTENTION! Secure all wiring away from any moving parts, pinch points or extreme heat. Kuryakyn WILL NOT warranty any electrical component that fails due to pinched, crimped, broken, abraded, melted or frayed wires.

STEP 6 Secure the neck cover using the 3/8" Flat Washer (thin) and 3/8"-16 High Crown Acorn Nut from the hardware kit to the gas tank mounting bolt; do not tighten at this time.

STEP 7 **On ABS models:** Remove the wire tie and clip that hold the ABS wire to the brake line on the right side. PIC 4 Install the corrugated wire cover over the ABS line and route it next to the wire harness to inside of the back panel of the headlight cowl. PIC 5 You will need about an inch of the corrugated cover sticking beyond the Chrome Neck Cover opening. PIC 6 You may use the supplied cable ties to tie this wire to the main harness. Install the Cord keeper to the inside of the headlight cowl back panel and hook it around the ABS wire. PIC 6 Place the left cover in place over the tank-mounting bolt. Make sure that the wires are behind the cover and not being pinched. The clutch cable remains on the outside of the neck cover.

STEP 8 Attach the left cover to the hex coupler nut using a #8-32 x 7/16" SHCS screw and #8 split lock washer, do not tighten at this time.

STEP 9 Place the 3/8" Flat Washer (thin) and 3/8"-16 High Crown Acorn Nut from the hardware kit to the gas tank mounting bolt; do not tighten at this point.

STEP 10 Tighten the #8-32 x 7/16" SHCS screws, from Step 8, being careful not to over tighten them.

STEP 11 Tighten the Acorn nuts on the gas tank-mounting bolt.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including preassembled) are tightened before operation of the motorcycle. Kuryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

STEP 12 Turn the handlebars in both directions to their full stop position to make sure that the clutch and throttle cables are not pinched or stretched. **On ABS models,** check that the rerouted ABS wire moves freely when the handlebars are turned lock to lock and does not get pinched in the fork stop.

WARNING!
STRETCHED OR PINCHED CABLES CAN CAUSE LOSS OF CONTROL THAT COULD RESULT IN SEVERE INJURY OR DEATH.

