




# INSTALLATION INSTRUCTIONS

## HONDA GOLDWING BALANCERS PART NO. MGW100-102 / MGW100-103

### FRONT WHEEL INSTALLATION

- STEP 1** Remove wheel from motorcycle
- STEP 2** Remove wheel weights, they are no longer necessary
- STEP 3** Remove left and right rotors
- STEP 4** Clean back of rotor where it contacts the wheel. This should be done with a wire brush
- STEP 5** Place balancer on the wheel with the balancer ring facing the wheel
- STEP 6** Place rotor on the wheel
- STEP 7** Replace new rotor bolts per manufacturers recommendations
- STEP 8** Apply thread lock, then re-install bolts
- STEP 9** Tighten rotor bolts to manufacturers specifications



### REAR WHEEL INSTALLATION

- STEP 1** Remove all 5 lug nuts
- STEP 2** Remove wheel from hub
- STEP 3** Remove wheel weights, they are no longer necessary
- STEP 4** Place rear balancer on the hub with the balancer ring facing the wheel
- STEP 5** Place the rear wheel back on the hub
- STEP 6** Replace lug nuts and tighten to manufacturers specifications



**THANK YOU FOR CHOOSING CENTRAMATIC!**

*Pictures are not model specific, and are only shown as a visual aid for some of the steps. They do not show the entire installation process.*

For technical support and dealer inquires please contact:

KEYSTONE DISTRIBUTING | 949.268.9005 | 185 AVENIDA LA PATA | SAN CLEMENTE, CA 92673