

Motorcycle Victory Installation Instructions

Rear Wheel Installation:

- *Remove rear wheel.
- *Remove Drive Pulley
- *Clean hub and Drive Pulley surfaces of any corrosion.
- *Place balancer on hub with flat surface towards pulley.
- *Place Drive Pulley on top of balancer.

Victory Recommends Using new Drive Pulley Bolts

- *If reusing existing Drive Pulley nuts or bolts use thread locker on threads (Loctite) before reinstalling.
- *Torque nuts or bolts bolts to spec for your model per Victory

Front Wheel Installation:

- *Remove front wheel.
- *Remove brake rotor (or rotors) one at a time.
- *Clean hub and rotor surfaces of any corrosion.
- *Place balancer on hub with flat surfaces towards brake rotor or rotors.
- *Place brake rotor on top of balancer.

Victory Recommends Using New Rotor Bolts.

- *If reusing existing rotor bolts use thread locker on threads (Loctite) before reinstalling.
- *Torque rotor bolts to spec for your model per Victory.
- *Spread brake pads so they will center on rotor after wheel is reinstalled (pump up front brakes).
- *For ABS models refer to your Victory factory specs for proper ABS Sensors clearance
- *If you have any questions about fitment or installation call 855-448-8473.

ALWAYS FOLLOW MANUFACTURERS RECOMMENDATIONS FOR WHEEL AND BRAKE REMOVAL AND INSTALLATION.