

Mounting Suggestions Yamaha Roadliner 2006-2010 & Stratoliner 2006-2011 Two-Piece Seat

Tools Required: • 10 mm socket

10 mm wrench

Hardware: • Stock Rear Seat Mounting Bolts



Baseplate Features:

The two-piece, marine-grade fiberglass baseplate is a direct replacement for the stock, two-piece seat. Rubber bumpers are positioned to prevent the seat from touching the frame and fender.

Stock Seat Removal Steps

- 1. Remove stock seat by inserting the ignition key into the left side cover and turning it counterclockwise. This will unlock the nose of the seat. Lift nose of the seat up a few inches, then forward and off the motorcycle.
- 2. With solo seat removed, use a 10 mm socket to remove the 2 rear seat mounting bolts from fender bracket.
- 3. Lift front of rear seat up then forward to remove.





Step 2



Mounting of Mustang Seat

Our seat is installed just like the stock seat. The passenger seat must be installed first.

Passenger Seat

- 1. Slide the tongue on the rear seat bracket into the Ubracket on the fender.
- 2. Push the seat back until the seat bracket aligns with the front fender bracket holes.
- 3. Install the stock 8 mm bolts through bracket and tighten with a 10 mm wrench.

Solo Seat

- 4. Slide the solo seat rear bracket into the fender mounted receiver. *Note: Make sure that the tool bag is not overstuffed and be sure it sits into the frame as low as possible.*
- 5. Push the solo seat back until it stops.
- 6. Align the nose bracket with the frame receiver and push down until a click is heard. The solo is now locked. To remove solo, insert ignition key into the left side cover and turn counterclockwise. The nose is now unlocked.

Step 1





Step 4





Enjoy the comfort of your new Mustang Seat!

V@•^Ác]•Áæ^Á* ãå^|āj^•ÁţÁ@|]Á[*Áşj•cæ‡|Á[*¦Á,^,ÁT*•cæ);*Á,¦[å*&dÈkQÁ[*Á,^^åÁ*¦c@} æ•ã cæ);&^Á,|^æ^Á&æ‡|Á*•ÁæeÂ,€EËCIHËHUGÊAT[}åæ`Ác@[*®ÁzIãaæ`ÁJH€€ÆÄÄ,KH€ÆÖæe cº¦}Á,¦Á^}å æ);ÁE; æā‡ÁţÁ*^•cāţ}•O{*•cæ);*•^æenÈ&[{Á;¦Áşã*ãaÁ*`¦Á,^à•ãe^Á&æeÁ,`,`,È;*•cæ);*•^æenÈ&[{È Á Q[¦Á&æd^Áæ};åÁ;æāj:c^}æ);&^A;~Á;*¦Á*^æenÊÅ,|^æe^Á*[Áţ[Áş];Å,^à•ãe^Ãc^Á*}å^¦Á?U*]][¦cÄÈ Á

Ü^~Đǎ, æko Ákor ÁlÎF GO ĐÂLÎF GHĐÂLÎF GIĐÂLÎF GIĐÂLÎF GIĐÂLÎÍ Í ĐÂLÎÍ Í JĐÂLJIÍ GĐÂLJIÍ HĐÂLJIÍ I ĐÂLJIÍ