





Baseplate Features:

The two-piece, marine grade fiberglass baseplate directly replaces the stock seat. Rubber bumpers are positioned to minimize vibration and protect the frame and fender.

Removal of Stock Two-Piece Seat:

- 1. Insert ignition key into the left side cover and turn counterclockwise to unlock front solo seat.
- 2. Lift front of solo up and off the frame.





- 3. The stock rear seat 's two 6mm mounting bolts are now accessible. Use a 10mm socket with extension to reach bolts and then remove.
- 4. With bolts removed, slide rear seat up and then forwar d to di sengage seat rear bracket from frame.





Page 1 of 2

Mounting of Mustang Seat:

Mustang's seat installs just like the Yamaha factory seat.

 Place the passenger seat on the fender, then slide it back to engage seat's rear bracket into the fender's U-bracket. Install Yamaha's 6mm bolts to the front fender bracket. Tighten with a 10mm socket.



Turn the ignition key in the left side cover counterclockwise t o unl ock the front lat ch mechanism.



3. Align the solo seat's re ar bracket with the fender receiver. Slide seat all the way back and push the nose of the seat down until a click is heard. The seat is now locked.





c you for choosing Mustang and enjoy your ride.

These steps are guidelines to help you install your new Mustang Product. If you need further assistance, please call us at 800-243-1392 or 860-582-9633, Monday through Friday 9:00 – 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Ref. part #76562, 76563, 79476, 79477