



**TWISTED  
THROTTLE**.COM

*Bolt-On Touring Accessories that fit YOUR motorcycle!*

## Accessory Mounting Bracket for SW-Motech & Givi Sidecarriers

**PEL.00.1120**

- Fits most cases smaller than 10" wide by 7" tall
- Allows use of quick release luggage



### PLEASE READ BEFORE INSTALLING

TWISTED THROTTLE products should be installed by a qualified, experienced motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. TWISTED THROTTLE takes no responsibility for damages caused by improper installation.

Medium strength liquid thread-locker (i.e., "Locktite") should be used to secure all screws, bolts, and nuts.

All screws, bolts, and nuts should be checked after driving the first 30 miles (50 km) to ensure that all are tightened to the proper torque.

All screws, bolts, and nuts, including all replacement hardware provided by TWISTED THROTTLE should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used:

M5.....	3.5 ft-lbs (5 Nm)
M6.....	6.5 ft-lbs (9 Nm)
M8.....	16 ft-lbs (22 Nm)
M10.....	32 ft-lbs (43 Nm)
M12.....	55 ft-lbs (75 Nm)



Instruction Rev: 00

Twisted Throttle LLC  
570 Nooseneck Hill Rd  
Exeter, RI 02822


Phone: 401.284.4200  
Fax: 401.223.6954  
www.twistedthrottle.com

## Step 1

**1**  
Bracket  
KFT.00.001  
Qty.....1



**2**  
Lens Head Screw  
M6x30.....ISO 7380  
Qty.....2



**3**  
Countersunk Screw  
M6x40.....DIN 7991  
Qty.....2



**4**  
Nyloc Nut  
M6.....DIN 985  
Qty.....4



## Step 2


**5**  
Lens Head Screw  
M6x20.....ISO 7380  
Qty.....2



**6**  
Sealing Washer  
M6  
Qty.....2



**7**  
Spacer  
#AS62-14-8  
Qty.....2

**Step One:** Bolt the mounting bracket to the rack using the included hardware. See diagram for installing with Trax Side cases.

**Step Two:** Place the case against the bracket and mark the hole pattern on the case. Using a 6mm drill bit, drill through the back side of the case. Using the included hardware, bolt the case to the rack.