

Part Number: BMW-S10XR-20(E) & BMW-S10XR-20-G(E)

Description: Canyon Dual Sport & Gunfighter Saddles

Fitment: 2020-2025 BMW S1000 XR & 2024 M1000 XR

Revision: 1

Corbin

Tools Required	Parts List
Phillips Screwdriver T-25 Torx wrench Needlenose Pliers	1 #CB-PWR-HRN-36=12" Wiring Harness / pigtail 1 #FACC-05 Small Fuse Adapter 1 Small fuse box rain cover 1 6" Zip tie

1. Begin by removing the stock seat (refer to your owner's manual).

2. Canyon Dual Sport installs like stock with two tabs in the front and a latch bracket in the rear. Simply engage the tabs at the front under the stock seat mounts and lower the seat into place. The Corbin latch pin will integrate with your BMW seat lock. *(Figure 1)*



HEATER INSTALLATION:

1. If you ordered the heated model, we also included a wiring pigtail that hooks into your stock fuse connector, so start by removing the bolt on the left side panel, using a T-25 torx wrench *(Figure 2)*.

2. Pop off the side panel by pulling straight towards you *(Figure 3)*.



3. Locate the fuse box *(Figure 4)*.

4. Remove the 7.5 amp fuse *(Figure 5)* and insert the fuse into the adapter at the end of the wiring pigtail *(Figure 6)*.

5. Insert the adapter in the space previously occupied by the 7.5 amp fuse *(Figure 7)*.

6. With the pigtail in place, the stock cover will not go back onto your fusebox. Insert the adapter through the included rain cover, then cover the entire fusebox with the rain cover *(Figure 8)*.



7. Attach the ground wire to the negative terminal on the battery (Figure 9), using a Phillips screwdriver.

8. Feed plug under the frame, then plug the two pigtails together (Figure 10).

9. Bundle loose wiring and secure it out of the way with the included zip tie (Figure 11). Do not tighten excessively or you may damage the wiring... just secure it in place for cleanliness.






10. Plug in seat and test. To do this, just plug the pigtail into the seat, turn on your ignition switch and flip the switch on the saddle. If the switch illuminates, the saddle heater is working.

11. Reinstall the side cover.

12. Proceed with saddle mounting as outlined above.

Enjoy your new saddle!

NOTE: The heater is controlled by the switch along the side of the saddle. The temperature is regulated by an internal thermostat when the heater switch is turned on.



Questions? Give us a holler...
800-223-4332
tech@corbin.com