



FITTING INSTRUCTIONS FOR CP0367 EXTENDED CRASH PROTECTORS
KTM 1290 SUPER DUKE R 2014



PICTURE A




PICTURE B

THIS KIT CONTAINS THE ITEMS PICTURED AND LISTED BELOW.
DO NOT PROCEED UNTIL YOU ARE SURE ALL PARTS ARE PRESENT.

Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike

THE PARTS SHOWN MAY BE REPRESENTATIVE ONLY (FOR CLARITY OF INSTRUCTIONS ONLY)

TOWARDS REAR
OF BIKE





TOWARDS FRONT
OF BIKE




PICTURE C



LEFT HAND SIDE



RIGHT HAND SIDE





LEGEND

- ITEM 1 = BC0002 Bobbin Caps (x2).
- ITEM 2 = M10 x 1.25 x 75mm LONG HEX HEAD BOLTS (CRASH PROTECTOR BOLTS) (x2).
- ITEM 3 = M10 WASHERS (x4).
- ITEM 4 = LW0001 (SHAKE PROOF WASHERS) (x2).
- ITEM 5 = B0061 with CS341 (10mm) (BOTH CRASH PROTECTORS) (x2).
- ITEM 6 = S0507 (SPACERS AERO SHAPED 20mm WIDE) (x2).
- ITEM 7 = NC0001 BOLT COVERS (x2).
- ITEM 8 = M0394 LEFT HAND SIDE WELDED ASSEMBLY (x1).
- ITEM 9 = M10 x 1.5 x 70mm LONG HEX HEAD BOLTS (FRAME BOLTS) (x2).
- ITEM 10 = S0050 (SMALL SPACER 7mm WIDE) (x2).
- ITEM 11 = M0395 RIGHT HAND SIDE WELDED ASSEMBLY (x1).
- ITEM 12 = SELF ADHESIVE NEOPRENE FOAM (2x100mm LENGTHS) NOT SHOWN.

Please note that in cases where kits are packed with rubber washers holding the components onto the bolt – *the rubber washers should be thrown away!*

TOOLS REQUIRED

- Socket set to include 17mm socket and wrench.
 - T45 Torx bit.
- Torque wrench (up to 40Nm).



Picture 1



Picture 2



Picture 3



Picture 4



Picture 5



Picture 6



Picture 7



Picture 8



Picture 9



Picture 10



Left-hand side (as you sit on bike)

- REMOVE THE ENGINE BOLTS IN POSITION ARROWED IN PICTURE 1.
- CUT AND STICK THE SELF ADHESIVE FOAM STRIP (ITEM 12) TO THE MOUNTING FACES OF THE LEFT HAND SIDE CRASH PROTECTOR MOUNTING BRACKET (ITEM 8) AS SHOWN IN PICTURE 2.
- PLACE THE M10 PLAIN WASHER (ITEM 3) ONTO THE M10x70mm LONG HEX HEAD BOLT (ITEM 9) **PLEASE NOTE THIS IS THE BOLT WITH THE COARSER PITCH**, PASS THE BOLT AND WASHER THROUGH THE CRASH PROTECTOR MOUNTING BRACKET (ITEM 8) AS SHOWN IN PICTURES 3 AND 4.
- PLACE THE SMALLER ROUND SPACER (ITEM 10) OVER THE EXPOSED END OF THE BOLT AS SHOWN IN PICTURES 3 AND 4.
- OFFER THIS ASSEMBLY INTO POSITION AS SHOWN IN PICTURES 5 AND 6.
- TIGHTEN THE BOLT TO NO MORE THAN 40Nm TORQUE.
- FIT THE RUBBER BOLT COVER (ITEM 7) ONTO THE BOLT (IT IS ADVISABLE TO USE A SMALL AMOUNT OF GLUE TO SECURE IN POSITION).
- PLACE THE M10 PLAIN WASHER (ITEM 3) ONTO THE M10x75mm LONG HEX HEAD BOLT (ITEM 2) **PLEASE NOTE THIS IS THE BOLT WITH THE FINER PITCH**, PLACE THE SHAKE PROOF WASHER (ITEM 4) ONTO THE BOLT UP TO PLAIN WASHER, PASS THE BOLT AND WASHERS THROUGH THE CRASH PROTECTOR (ITEM 5) SO WASHERS GO INTO RECESS AS SHOWN IN PICTURE 8.
- PLACE ONE OF THE AERO SPACERS (ITEM 6) OVER EXPOSED END OF BOLT AND UP TO THE CRASH PROTECTOR AS SHOWN IN PICTURE 8.
- OFFER THE ASSEMBLY INTO THE MOUNTING HOLE AS SHOWN IN PICTURES 9 AND 10. **PLEASE NOTE THE CRASH PROTECTOR (SLIDER) MUST BE POSITIONED AS SHOWN IN PICTURE C WITH BIGGER END TOWARD FRONT OF BIKE AND TIGHTEN.** (DO NOT EXCEED 40Nm TORQUE).
- FIT CRASH PROTECTOR CAP (ITEM 1) TO THE CRASH PROTECTOR.



Picture 11



Picture 12



Picture 13



Picture 14



Picture 15



Picture 16



Picture 17



Picture 18



Picture 19



Picture 20

Right-hand side (as you sit on bike)

- REMOVE THE ENGINE BOLTS IN POSITION ARROWED IN PICTURE 11.
- CUT AND STICK THE SELF ADHESIVE FOAM STRIP (ITEM 12) TO THE MOUNTING FACES OF THE RIGHT HAND SIDE CRASH PROTECTOR MOUNTING BRACKET (ITEM 11) AS SHOWN IN PICTURE 12.
- PLACE THE M10 PLAIN WASHER (ITEM 3) ONTO THE M10x70mm LONG HEX HEAD BOLT (ITEM 9) **PLEASE NOTE THIS IS THE BOLT WITH THE COARSER PITCH**, PASS THE BOLT AND WASHER THROUGH THE CRASH PROTECTOR MOUNTING BRACKET (ITEM 11) AS SHOWN IN PICTURES 13 AND 14.
- PLACE THE SMALLER ROUND SPACER (ITEM 10) OVER THE EXPOSED END OF THE BOLT AS SHOWN IN PICTURES 13 AND 14.
- OFFER THIS ASSEMBLY INTO POSITION AS SHOWN IN PICTURES 15, 16 AND 17.
- TIGHTEN THE BOLT TO NO MORE THAN 40Nm TORQUE.
- FIT THE RUBBER BOLT COVER (ITEM 7) ONTO THE BOLT (IT IS ADVISABLE TO USE A SMALL AMOUNT OF GLUE TO SECURE IN POSITION).
- PLACE THE M10 PLAIN WASHER (ITEM 3) ONTO THE M10x75mm LONG HEX HEAD BOLT (ITEM 2) **PLEASE NOTE THIS IS THE BOLT WITH THE FINER PITCH**, PLACE THE SHAKE PROOF WASHER (ITEM 4) ONTO THE BOLT UP TO PLAIN WASHER, PASS THE BOLT AND WASHERS THROUGH THE CRASH PROTECTOR (ITEM 5) SO WASHERS GO INTO RECESS AS SHOWN IN PICTURE 18.
- PLACE ONE OF THE AERO SPACERS (ITEM 6) OVER EXPOSED END OF BOLT AND UP TO THE CRASH PROTECTOR AS SHOWN IN PICTURE 18.
- OFFER THE ASSEMBLY INTO THE MOUNTING HOLE AS SHOWN IN PICTURES 19 AND 20. **PLEASE NOTE THE CRASH PROTECTOR (SLIDER) MUST BE POSITIONED AS SHOWN IN PICTURE C WITH BIGGER END TOWARD FRONT OF BIKE AND TIGHTEN.** (DO NOT EXCEED 40Nm TORQUE).
- FIT CRASH PROTECTOR CAP (ITEM 1) TO THE CRASH PROTECTOR.

ISSUE 1 20/03/2014 (NSY)

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular



purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorized (if not pre-authorized the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in re-sellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.



INSTRUCTIONS DE MONTAGE POUR CP0367 PROTECTIONS CRASH
KTM 1290 SUPER DUKE R 2014



PHOTO A



PHOTO B

LE KIT CONTIENT LES ARTICLES EXPOSES CI-DESSOUS, VERIFIER QUE TOUTES LES PIECES SOIENT PRESENTES AVANT DE PROCEDER AU MONTAGE.

La façon dont le kit est emballé ne correspond pas forcément à la façon de monter les pièces sur la moto

LES PARTIES PRESENTEES PEUVENT ETRE UNIQUEMENT REPRESENTATIVES (POUR LA CLARTE DES INSTRUCTIONS UNIQUEMENT).



Arrière moto





Avant moto



Coté gauche



Coté droit





LEGENDE

- ARTICLE 1 = BC0002 CAPUCHONS DE BOBINE (x2).
ARTICLE 2 = M10 x 1.25 x 75mm BOULONS (Boulons de protection crash) (x2).
ARTICLE 3 = M10 RONDELLES (x4).
ARTICLE 4 = LW0001 (RONDELLES ANTI VIBRATION) (x2).
ARTICLE 5 = B0061 avec CS341 (10mm) (LES 2 PROTECTIONS CRASH) (x2).
ARTICLE 6 = S0507 (ENTRETOISE FORME AERO 20mm D'ÉPAISSEUR) (x2).
ARTICLE 7 = NC0001 CACHE BOULON (x2).
ARTICLE 8 = M0394 ASSEMBLAGE SOUDE COTE GAUCHE (x1).
ARTICLE 9 = M10 x 1.5 x 70mm BOULONS (BOULONS CADRE) (x2).
ARTICLE 10 = S0050 (PETITE ENTRETOISE 7mm D'ÉPAISSEUR) (x2).
ARTICLE 11 = M0395 ASSEMBLAGE SOUDE COTE DROIT (x1).
ARTICLE 12 = MOUSSE NEOPRENE AUTOCOLLANTE (2x100mm DE LONG) NON INDIQUE.

Notez que si les kits sont emballés avec des rondelles en caoutchouc servant à tenir les composants, *ces rondelles doivent être jetées.*

Outils requis

- Clés à douille 17mm
 - Clé Torx T45
- Clé dynamométrique (à 40 Nm).



Photo 1



Photo 2



Photo 3



Photo 4



Photo 5



Photo 6



Photo 7



Photo 8



Photo 9



Photo 10

Coté gauche (assis sur la moto)

- Enlever les boulons moteur (PHOTO 1).
- Couper puis coller le bandeau autocollant (ARTICLE 12) sur les faces du support du coté gauche du support de fixation (ARTICLE 8) (PHOTO 2).
- Placer la rondelle M10 (ARTICLE 3) sur le boulon M10x70mm (ARTICLE 9) **NOTEZ QU'IL S'AGIT DU BOULON AVEC LE GROS BOUT**, passer le boulon et la rondelle à travers le support de fixation de la protection crash (ARTICLE 8) (PHOTOS 3 et 4).
- Placer la petite entretoise (ARTICLE 10) autour de l'extrémité du boulon (PHOTOS 3 et 4).
- Poser l'ensemble en position (PHOTOS 5 et 6).
- Serrer le boulon sans dépasser 40Nm de couple.
- Placer le cache boulon en caoutchouc (ARTICLE 7) sur le boulon (il est conseillé d'utiliser un peu de superglue pour fixer la position).
- Placer la rondelle M10 (ARTICLE 3) sur le boulon M10x75mm (ARTICLE 2) **NOTEZ QU'IL S'AGIT DU BOULON AVEC LE BOUT FIN**, Placer la rondelle anti vibration (ARTICLE 4) sur le boulon sur la rondelle plate. Passer le boulon et ses rondelles à travers la protection crash (ARTICLE 5) pour que les rondelles aillent dans le creux (PHOTO 8).
- Placer une des rondelles aéro (ARTICLE 6) autour de l'extrémité du boulon et sur la protection crash (PHOTO 8).
- Monter l'ensemble en position dans le trou de fixation (PHOTOS 9 et 10). **LA PROTECTION DOIT ETRE POSITIONNEE COMME EN "C" AVEC LE COTE ARRONDI LE PLUS GROS EN DIRECTION DE L'AVANT DE LA MOTO PUIS SERRER** (Pas plus de 40 Nm de couple).
- Mettre le capuchon de protection (ARTICLE 1) sur la protection crash.



Photo 11



Photo 12



Photo 13



Photo 14



Photo 15



Photo 16



Photo 17



Photo 18



Photo 19



Photo 20

Coté droit (assis sur la moto)

- Enlever les boulons moteur (PHOTO 11).
- Couper puis coller le bandeau autocollant (ARTICLE 12) sur les faces du support du coté droit du support de fixation (ARTICLE 11) (PHOTO 12).
- Placer la rondelle M10 (ARTICLE 3) sur le boulon M10x70mm (ARTICLE 9) **NOTEZ QU'IL S'AGIT DU BOULON AVEC LE GROS BOUT**, passer le boulon et la rondelle à travers le support de fixation de la protection crash (ARTICLE 11) (PHOTOS 13 et 14).
- Placer la petite entretoise (ARTICLE 10) autour de l'extrémité du boulon (PHOTOS 13 et 14).
- Poser l'ensemble en position (PHOTOS 15, 16 et 17).
- Serrer le boulon sans dépasser 40Nm de couple.
- Placer le cache boulon en caoutchouc (ARTICLE 7) sur le boulon (il est conseillé d'utiliser un peu de superglue pour fixer la position).
- Placer la rondelle M10 (ARTICLE 3) sur le boulon M10x75mm (ARTICLE 2) **NOTEZ QU'IL S'AGIT DU BOULON AVEC LE BOUT FIN**, Placer la rondelle anti vibration (ARTICLE 4) sur le boulon sur la rondelle plate. Passer le boulon et ses rondelles à travers la protection crash (ARTICLE 5) pour que les rondelles aillent dans le creux (PHOTO 18).



- Placer une des rondelles aéro (ARTICLE 6) autour de l'extrémité du boulon et sur la protection crash (PHOTO 18).
- Monter l'ensemble en position dans le trou de fixation (PHOTOS 19 et 20). **LA PROTECTION DOIT ETRE POSITIONNEE COMME EN "C" AVEC LE COTE ARRONDI LE PLUS GROS EN DIRECTION DE L'AVANT DE LA MOTO PUIS SERRER** (Pas plus de 40 Nm de couple).
- Mettre le capuchon de protection (ARTICLE 1) sur la protection.

ISSUE 1 20/03/2014 (NSY)

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorized (if not pre-authorized the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in re-sellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.